



**New  
formula**

Ready-to-use wipes for the disinfection of all kinds of surfaces.

## kodan® (N) wipes

### Our Plus

- short contact times
- broad disinfection range
- in toilet facilities and changing mats
- dermatologically tested

### Application areas

The kodan® (N) wipes are suitable for the disinfection and cleaning of all non-medical surfaces.

For example:

- door handles
- work surfaces
- toilet facilities
- changing mats

### Instructions for use

Make sure that all visible soiling is removed before disinfection. Thoroughly wipe the surface with the impregnated cloth and allow to take effect. Thoroughly wipe the surface with the impregnated cloth and allow to take effect. When opening and inserting the first cloth, ensure that hygiene requirements are maintained. Make sure to close the lid tightly after use. Do not treat surfaces that are sensitive to alcohol, e.g. acrylic glass.

schülke guarantees, if used in the correct way, a shelf life of 3 months after the package has been opened.

#### Following sizes are available:

- kodan® (N) wipes: 10 tubs per carton containing 90 wipes; Ø14 cm x 22 cm
- kodan® (N) wipes refill: 20 refills per carton containing 90 wipes; Ø14 cm x 22 cm

### Microbiological efficacy

Efficacy	Concentration	Contact time
<b>bactericidal</b> EN13727, EN16615 - dirty conditions	ready-to-use	1 min.
<b>bactericidal</b> - dirty conditions	ready-to-use	1 min.
<b>tuberculocidal</b> EN14348 - dirty conditions	ready-to-use	1 min.
<b>yeastocidal</b>	ready-to-use	1 min.
<b>yeastocidal</b> EN13624 - dirty conditions	ready-to-use	1 min.
<b>yeastocidal</b> EN16615 - dirty conditions	ready-to-use	1 min.
<b>fungicidal</b> EN13624 - dirty conditions	ready-to-use	2 min.
<b>virucidal against enveloped viruses</b> in accordance with DVV (German Registered Association for Combating Viral Diseases)//RKI Guideline	ready-to-use	30 sec.
<b>Norovirus</b> EN14476	ready-to-use	1 min.
<b>Rotavirus</b> in accordance with DVV	ready-to-use	30 sec.
<b>Adenovirus (type 5)</b> in accordance with DVV (German Registered Association for Combating Viral Diseases)//RKI Guideline	ready-to-use	5 min.



# kodan<sup>®</sup> (N) wipes

## Product data

### Composition:

100 g solution contain the following active ingredients:

25 g Ethanol (94%w/w), 35 g Propan-1-ol

Labelling according to Regulation (EC) No. 648/2004:  
perfumes

### Chemical-physical data

Color	colourless
Density	ca. 0,89 g/cm <sup>3</sup> / 20 °C / of the active solution
Flash point	27 °C / Method : DIN 51755 Part 1 / of the active solution
Form	Aqueous, alcohol containing solution on non-woven
pH	ca. 7 / 20 °C / of the active solution
Viscosity, dynamic	No data available

## Special advice

### Use disinfectants safely. Always read the label and product information before use.

The product is highly compatible with metals and synthetics (except acrylic glass and alcohol-sensitive varnishes). Please follow carefully any national fire and explosion protection guidelines when using alcohol-based disinfectants. Only treat small surfaces. The wiping range depends on the room temperature and on the structure of the surface to be disinfected. More information available on request.

### Refilling of the tin

First disinfect hands and wear new protective gloves. During the refilling process, please ensure that the gloves are not contaminated by other activities. On every refill, reprocess the lid closure. In reprocessing, subject the lid closure to disinfectant cleaning with an alcohol based surface disinfectant.

## Information for order

Item	Delivery form	Item no.
kodan <sup>®</sup> (N) wipes refill (20 x 90 wipes)	20/Carton	on request
kodan <sup>®</sup> (N) wipes (10 x 90 wipes)	10/Carton	on request

These products are not available in every country. For more information please contact our local subsidiary or distributor.

## Application aids

Application aids	Item no.
Wall mounting for the dispenser (small)	134417

## Related Products

- mikrozyd<sup>®</sup> AF wipes
- mikrozyd<sup>®</sup> sensitive wipes
- mikrozyd<sup>®</sup> universal wipes premium



Schülke & Mayr GmbH holds a Manufacturer's Authorisation according to sect 13 para 1 German Drug Law and Certificates of GMP Compliance for medicinal products.

**schülke Headquarters**  
Schülke & Mayr GmbH  
Robert-Koch-Str. 2  
22851 Norderstedt, Germany  
Phone +49 40 - 52100 - 0  
Fax +49 40 - 52100 - 318  
www.schuelke.com  
info@schuelke.com